QUICK START GUIDE

REV | #1.15

TACTICAL ALTIMETERS

Manual for Download and Support
WWW.LBALTIMETERS.COM

ALFA - QUICK START & ROAD MAP

Quick Buttons
Press and hold button for 5 seconds



Performing ACCESS to Logbook and Jump Info

Press and release

Press

-------- hold button down-------

Release

Logbook and Jump Info window

Performing ACCESS to Settings

Perform ACCESS to Logbook and Jump Info

Press

--- hold for 5 seconds---

Release

Settings Window


ACCESS
Daily Jump Counter
Total Jumps
Exit Altitude
Opening Altitude
Freefall Time
Average Freefall Speed
Maximum Freefall Speed
Altitude Profile Last Jump
Speed Profile Last Jump
Exit Logbook
LOGBOOK and JUMP INFO
Press to rotate selection
Press or for information


ACCESS to Settings
Year
Date
Time
Jump Counter
Altitude Units
Speed Units
Dive Type
Delete Last Jump
Delete Logbook
Turn OFF
Exit Settings
SETTINGS
Press to rotate selection or confirm
Press or to change settings