



### Power up display



### Logbook Screen # 1. (Main information)



Scrolls automatically through AVG, MAX and MIN speeds.

To scroll through the previous jumps, press

To scroll forward, press

To go to highest jump #, press and hold for 3 seconds

To go to lowest jump #, press and hold for 3 seconds

### Main Display

(If no button has been pressed within 5 minutes, the ALITRACK will return to this window)

Press or to toggle between current date and time

Current time (24 hour format)  
or  
Current date (format: yyyy:mm:dd)



Current temperature inside instrument in Celsius or Fahrenheit


Current altitude

Freefall and canopy log status

### MAIN SELECTOR

Press and hold for 3 seconds to enter the SETUP SELECTOR

### Logbook Screen # 2. (Playback, Jump Profile)



Time after exit in seconds and 1/4 seconds

Temperature inside instrument at exit and then updated every 30 sec.


Press to playback the jump profile and press to playback the jump profile in reverse.

Press to stop playback

Press AND at the same time to playback jump on analog face. Wait for pointer to go to EXIT point, then press "Left Front Button" to start playback.

Press "Right Front Button" to stop playback

### Logbook Screen # 3. (Date, Time and Dive Type)



To scroll through the previous jumps press

To change direction, press


TURN FOR SETUP SELECTOR

# ALTI**TRACK**

## ROADMAP

### SETUP SELECTOR

#### Beep ON / OFF




Press **[ON/OFF]** to toggle between BEEP ON/OFF.

#### Celsius / Fahrenheit Selector




Press **[C/F]** to toggle between Celsius and Fahrenheit.

#### Dive Type Selector




Press **[DIVE TYPE]** ("DIVE TYPE" flashes).  
 Press **[RIGHT]** to scroll forward through the Dive Type list.  
 Press **[LEFT]** to scroll backward through the Dive Type list.  
 Press **[ENTER]** to store your selection.

#### Canopy Log Enable / Disable




Press **[ON/OFF]** to enable / disable canopy profile log.  
**[DIVE TYPE] + [ON/OFF]**: Logging freefall and canopy profiles  
**[DIVE TYPE]**: Logging freefall profile

#### True Airspeed (TAS) / Skydiver's Airspeed




Press **[TAS/SAS]** to toggle between TAS and SAS.

#### Feet / Meter Selector




Press **[FT/MTR]** to toggle between FT and MTR.

#### MPH / KMH Selector




Press **[MPH/KMH]** to toggle between MPH and KMH.

#### Main Setup Display




Press **[RIGHT]** to move forward in setup options.  
 Press **[LEFT]** to move backward in setup options.

#### Turn the ALTI**TRACK** OFF




Press **[ON/OFF]** ("OFF" flashes).  
 Press **[RIGHT]** to increase the counter to "Match Value".  
 Press **[LEFT]** to decrease counter to the "Match Value".  
 At "Match Value" press **[ON/OFF]**.  
 The pointer will move to the 6 o'clock position and the unit turns OFF.

#### Delete Jump




Press **[DELETE]** ("Delete Jump Icon" flashes).  
 Press **[RIGHT]** to increase the counter to "Match Value".  
 Press **[LEFT]** decrease counter to the "Match Value".  
 At "Match Value" press **[DELETE]** to delete current jump.

#### Set Total Jumps




Press **[TOTAL]** ("TOTAL" flashes).  
 Press **[RIGHT]** to increase the jump total.  
 Press **[LEFT]** to decrease the jump total.  
 Press **[ENTER]** to store the new total number of jumps and end.

#### Set Total Freefall Time




Press **[TOTAL]** ("TOTAL" flashes).  
 Press **[RIGHT]** to increase total freefall time.  
 Press **[LEFT]** to decrease total freefall time.  
 Press **[ENTER]** to store the new freefall time and end.

#### Set Current Date




Press **[CLOCK]** ("Clock" icon flashes).  
 Press **[RIGHT]** to increase date value.  
 Press **[LEFT]** to decrease date value.  
 Press **[ENTER]** to store the new date and end.  
**NOTE:** Date format is YYYY:MM:DD.

#### Set Current Time



Press **[CLOCK]** ("Clock" icon flashes).  
 Press **[RIGHT]** to increase time value.  
 Press **[LEFT]** to decrease time value.  
 Press **[ENTER]** to store the new time and end.

#### Delete Logbook



Press **[DELETE]** ("Delete Logbook" icon flashes).  
 Press **[RIGHT]** to increase the counter to "Match Value".  
 Press **[LEFT]** to decrease counter to the "Match Value".  
 At "Match Value" press **[DELETE]** to delete logbook.

## SETUP SELECTOR

To leave a menu function, wait until the display times out or, press **[LEFT]** or **[RIGHT]** repeatedly until returning to the Main Setup Display, then press **[ON/OFF]** to exit.

**Note:** If no button has been pressed within 5 minutes after choosing any SETUP window, the ALTI**TRACK** will return to the Main display.

TURN FOR MAIN SELECTOR →