ROAD MAP



ECHO 3™ • REV. 1.0, FEBRUARY 2026

WARNING

This Road Map **does not replace the ECHO 3™ Manual** nor releases the user from the obligation to **comply with the contents of the ECHO 3™ Manual**.

TACTICAL ALTIMETERS


Visit lbaltimeters.com for manual and support

Instructional videos and YouTube channel


ACCESS

1. Press and release the **mode** button – the lock icon turns off
2. When the lock icon reappears, immediately **press and hold** the **mode** button – the lock icon turns off again
3. When the lock icon appears again, **release** the **mode** button. - The ECHO 3™ is now in **ACCESS** mode to Settings.

Note: The ECHO 3™ exits ACCESS and returns to the Main Window if no button has been pressed within 5 seconds. ALL functions (except Power ON) can be performed ONLY when the ECHO 3™ is in ACCESS mode.



The ECHO 3™ has been powered OFF prior to shipping from our factory. To turn the **power ON**, press and hold any key for 5 seconds.



To save battery power, the ECHO 3™ will switch OFF after 14 hours of inactivity. **Turn the unit ON before using it for skydiving**.

Main Window



Press and hold for 5 seconds



Altitude Offset



IR Mode

Backlight ON/OFF




ACCESS

Settings

Press or to change settings

- **Jump Mode** — mode 1
- **LED on/off** — LEd On
- **Scroll on/off** — ScroL OFF
- **Altitude Units** — Feet / Feet
- **Pitch** — P1 7
- **Sound Test** — Sound run
- **Sound Test** — Sound run
- **Guide on/off** — GuidE On
- **Guide Test** — GuidE run
- **Turn Off** — 0 5 OFF
- **Access to Warning Settings** — 0 9
- **Exit Settings**

Increase the left number to 9 using , then press to access Warning Settings.



Warning Settings

Press or to change settings

- **Climb to Altitude Warnings** — 4 3 2 1000 Feet
- **High Speed Warnings** — 4 3 2 16000 Feet
- **Low Speed Warnings** — 4 3 2 1200 Feet
- **ACCESS Code** — 9
- **Exit Warning Settings**