ROAD MAP

REV. 02, SEPTEMBER 2022

WARNING

This Road Map **does not replace the OPTIMA II™ Manual** nor releases the user from the obligation to **comply with the contents of the OPTIMA II™ Manual**.

ALTIMETERS

Visit Iba ltimeters.com for manual and support

Instructional videos and YouTube channel

ACCESS

1. Press and release the **mode** button – the lock icon turns off
2. When the lock icon reappears, immediately **press and hold** the **mode** button – the lock icon turns off again
3. When the lock icon appears again, **release** the **mode** button. - The OPTIMA II™ is now in **ACCESS** mode.

Note: The OPTIMA II™ exits ACCESS and returns to the Main Window if no button has been pressed within 5 seconds. ALL functions (except Power ON) can be performed ONLY when the OPTIMA II™ is in ACCESS mode.

The OPTIMA II™ has been powered OFF prior to shipping from our factory. To turn the **power ON**, press and hold any key until the unit beeps, then release the key.

To save battery power, the display will switch OFF after 14 hours of inactivity. However, the OPTIMA II™ is still ready for jumping. **Press any key** to display the Main Window.

Main Window

Clock

Low Speed

ACCESS

Return to main window

Set Time

1st Warning Altitude

Climb to Altitude Warning and Clock Selector

2nd Warning Altitude

3rd Warning Altitude

Warning Banks

1st Warning Altitude

2nd Warning Altitude

3rd Warning Altitude

Canopy Descent and Low Speed Warning Selector

Pitch

Sound Test

Sound Volume

Guide

Return to main window

Warning Banks

1st Warning Altitude

2nd Warning Altitude

3rd Warning Altitude

Pitch

Sound Volume

Sound Test

FT/MTR

Altitude Offset

Switch Off

High Speed Warning and Setup Selector