ROAD MAP

REV. 02, SEPTEMBER 2022

WARNING

This Road Map **does not replace the VISO II+™ Manual** nor releases the user from the obligation to **comply with the contents of the VISO II+™ Manual**.

ALTIMETERS

Visit Ibaltimeters.com for manual and support

Instructional videos and YouTube channel

ACCESS

1. Press and release the **mode** button ⊡ – the lock icon 🔒 turns off
2. When the lock icon 🔒 reappears, immediately **press and hold** the **mode** button ⊡ – the lock icon 🔒 turns off again
3. When the lock icon 🔒 appears again, **release** the **mode** button ⊡. - The VISO II+™ is now in **ACCESS** mode.

Note: The VISO II+™ exits ACCESS and returns to the Main Window if no button has been pressed within 5 seconds. ALL functions (except Power ON) can be performed ONLY when the VISO II+™ is in ACCESS mode.

ACCESS

1. Press and release the **down** button ▽ – the lock icon 🔒 turns off
2. When the lock icon 🔒 reappears, immediately **press and hold** the **down** button ▽ – the lock icon 🔒 turns off again
3. When the lock icon 🔒 appears again, **release** the **down** button ▽. - The VISO II+™ is now in **ACCESS** mode.

Note: The VISO II+™ exits ACCESS and returns to the Main Window if no button has been pressed within 5 seconds. ALL functions (except Power ON) can be performed ONLY when the VISO II+™ is in ACCESS mode.

The VISO II+™ has been powered OFF prior to shipping from our factory. To turn the **power ON**, press and hold any key until the unit beeps, then release the key.





Backlight

To turn backlight ON or OFF, hold ▽ for 2 seconds.

Daily Jump Counter

Press and hold ⊡ for 2 seconds

Press ▽ or ▽ to display jump counter for other dates.

ACCESS

ACCESS

Jump Profile

- Playback Altitude v time
- ⊡
- Playback Speed v time

Hold ⊡ for 5 seconds

Logbook information

- Jump number
- Exit altitude
- Deployment altitude
- Freefall time
- Max freefall speed
- Max canopy speed

Hold ⊡ for 5 seconds

VISO II+™ Setup Selector

- Altimeter/ Speedometer
- Feet/Meter when set to altimeter
- Mph/Kmh when set to speedo-meter
- Altitude offset
- Dive type
- True airspeed (TAS) / Skydiver's airspeed (SAS)
- Set current year
- Set current date

- Set current time
- Set jump counter
- Reset jump counter
- Turn the unit OFF
- Lock window